


	Switch Index	2–35
	Vertical Slide Switch	36–59
	Horizontal Slide Switch	60–69
	Push Switch	70–75
	Vertical Push Switch	76–81
	Button With Light Switch	82–107
	Tact Switch	108–113
	Mini Slide Switch	114–115
	Rocker Switch	116–160
	2.5/3.5 SMT Phone Jack	161–167
	2.5/3.5 DIP Phone Jack	168–176
	SMT DC Jack	177–179
	DIP DC Jack	180–185
	USB Connector	186–191

SWITCH INDEX




SS12F23 (P.40)

SS12F24
SS12F42 (P.40)

SS12F25 (P.40)




SS12F27 (P.40)



SS12F30 (P.40)



SS12F31 (P.40)




SS12F33 (P.40)



SS12F34 (P.40)



SS12F37 (P.40)




SS12F39 (P.40)



SS12F40 (P.40)



SS12F41 (P.40)

SS12F44
SS12F46 (P.41)SS12F45
SS12F65 (P.41)

SS12F47 (P.41)



SS12F48 (P.41)



SS12F49 (P.41)




SS12F50 (P.41)



SS12F55 (P.41)



SS12F58 (P.41)




SS12F68 (P.41)



SS12F89 (P.41)



SS12F92 (P.41)



SS12F117 (P.41)



SS12H01 (P.42)




SS12H03 (P.42)



SS12H11 (P.42)



SS12I04 (P.42)



SS12L04 (P.42)



SS12L07 (P.42)



SS13D01 (P.42)



SS13D03 (P.42)



SS13D04 (P.42)



SS13D10 (P.42)

SS13D13 L3R1
(P.42)

SS13D15 (P.43)

SWITCH INDEX



SS22J22 (P.49)

SS22K25
SS22K35 (P.49)

SS22K26 (P.49)



SS22K28 (P.49)



SS22K29 (P.49)



SS22K31 (P.49)



SS22K32 (P.49)




SS22L08 (P.49)



SS22L13 (P.49)



SS22L16 (P.49)



SS22L24 (P.49)



SS22N02 (P.49)



SS22P01 (P.50)



SS22P03 (P.50)



SS23D01 (P.50)




SS23D02 (P.50)



SS23D03 (P.50)



SS23D04 (P.50)



SS23D05 (P.50)



SS23D06 (P.50)



SS23D07 (P.50)



SS23D08 (P.50)



SS23D10 (P.50)



SS23D11 (P.50)



SS23D14 (P.51)



SS23D15 (P.51)



SS23D16 (P.51)



SS23D21 (P.51)



SS23D23 (P.51)



SS23D24 (P.51)



SS23D25 (P.51)



SS23D26 (P.51)



SS23D28 (P.51)



SS23D32 (P.51)



SS23E01 (P.51)



SS23E03 (P.51)


SWITCH INDEX



SK12D01 (P.60)



SK12D02 (P.60)



SK12D07 (P.60)



SK12D09 (P.60)



SK12D11 (P.60)



SK12D12 (P.60)



SK12D15 (P.60)



SK12D18 (P.60)



SK12D19 (P.60)



SK12E12 (P.60)



SK12E14 (P.60)



SK12F01 (P.60)



SK12F02 (P.61)



SK12F04 (P.61)



SK12F08 (P.61)



SK12F14 (P.61)



SK12F15 (P.61)



SK12F16 (P.61)



SK12H01 (P.61)

SK13D01 L1R3
SK13D11 L3R1
(P.61)

SK13D02 (P.61)



SK13D03 (P.61)



SK13D04 (P.61)




SK13D06 (P.61)



SK13D07 (P.62)



SK13D08 (P.62)




SK13D10 (P.62)

SK13D12 L3R1
(P.62)


SK13D18 (P.62)



SK13D21 (P.62)



SK14D01 (P.62)

SK14D02 L2R3
SK14D12 L3R2
(P.62)

SK14D03 (P.62)



SK15D01 (P.62)



SK15D02 (P.62)



SK22D02 (P.62)

SWITCH INDEX



SK42H04 (P.69)



SK42H13 (P.69)



SK43D01 L1R3
(P.69)



SK43D03 L1R3
(P.69)



SK43D08 L3R1
(P.69)



SK43D09 L3R1
SK43D10 L1R3
(P.69)



SK44D04 L3R2
(P.69)



SK62D01 (P.69)



SK62H01 L1R3
(P.69)






















SK62H03 L1R3
(P.69)



SK62H11 (P.69)



SK63D01 L1R3
SK63D10 L3R1
(P.69)



SWITCH INDEX



**PB-22E06 (SELF-LOCK)
PB-22E16 (NON-LOCK)
(P.75)**



**PB-22E08 (SELF-LOCK)
PB-22E18 (NON-LOCK)
(P.75)**



**PB-22E27 (SELF-LOCK)
PB-22E27-T (NON-LOCK)
(P.75)**



**PB-22E52 (SELF-LOCK)
PB-22E70 (NON-LOCK)
(P.75)**



**PB-22E60 (SELF-LOCK)
PB-22E70 (NON-LOCK)
(P.75)**



**PB-22E60A (SELF-LOCK)
(P.75)**



**PB-22E60A-DS (SELF-LOCK)
(P.75)**



**PB-22E68 (NON-LOCK)
(P.75)**



**PB-22E69 (NON-LOCK)
(P.75)**



**PB-22E601 (SELF-LOCK)
(P.75)**



**PB-22E603 (SELF-LOCK)
(P.75)**



PS11D33 (P.70)



PS11F03 (P.70)



**PS12D01 (NON-LOCKED)
(P.70)**



**PS12D33 (NON-LOCKED)
(P.70)**



**PS12E05 (LOCKED)
(P.70)**



PS12E052 (P.70)



PS12F03 (P.71)



PS12F03-W (P.71)



PS12F05 (P.71)



PS12F06 (P.71)



**PS22E02 (LOCKED)
PS22E03 (NON-LOCKED)
(P.71)**



**PS22E05 (LOCKED)
PS22E15 (NON-LOCKED)
(P.71)**



**PS22E08 (LOCKED)
(P.71)**



**PS22E051 (LOCKED)
(P.71)**



**PS22E081 (LOCKED)
(P.71)**



**PS22F02 (LOCKED)
PS22F03 (NON-LOCKED)
(P.71)**



PS22F04 (P.71)



**PS22F05 (LOCKED)
PS22F07 (NON-LOCKED)
(P.71)**



**PS22F06 (LOCKED)
PS22F12 (NON-LOCKED)
(P.72)**



**PS22F09 (LOCKED)
PS22F10 (NON-LOCKED)
(P.72)**



**PS22F11 (LOCKED)
PS22F13 (NON-LOCKED)
(P.72)**



PS22F14 (P.72)



**PS22F15 (LOCKED)
PS22F17 (NON-LOCKED)
(P.72)**



**PS22F16 (LOCKED)
PS22F19 (NON-LOCKED)
(P.72)**



**PS22F21 (LOCKED)
PS22F24 (NON-LOCKED)
(P.72)**

SWITCH INDEX



**PS22F22 (LOCKED)
PS22F23 (NON-LOCKED)
(P.72)**



**PS22F25 (LOCKED)
PS22F65 (NON-LOCKED)
(P.72)**



**PS22F26 (LOCKED)
PS22F32 (NON-LOCKED)
(P.72)**



**PS22F27 (LOCKED)
(P.72)**



**PS22F28 (LOCKED)
(P.72)**



**PS22F29 (LOCKED)
PS22F30 (NON-LOCKED)
(P.73)**



**PS22F31 (LOCKED)
PS22F34 (NON-LOCKED)
(P.73)**



**PS22F33 (NON-LOCKED)
PS22F35 (LOCKED)
(P.73)**



**PS22F36 (LOCKED)
(P.73)**



**PS22F37 (LOCKED)
(P.73)**



**PS22F38 (LOCKED)
(P.73)**



PS22F41 (P.73)



**PS22F43 (LOCKED)
(P.73)**



PS22F45 (P.73)



**PS22F46 (LOCKED)
(P.73)**



PS22F48 (P.73)



**PS22F56 (LOCKED)
(P.73)**



**PS22F60 (LOCKED)
PS22F61 (NON-LOCKED)
(P.74)**



PS22F63 (P.74)



**PS22F68-58 (LOCKED)
PS22F78 (NON-LOCKED)
(P.74)**



PS22F91 (P.74)



PS22F92 (P.74)



PS22F93 (P.74)



PS22F94 (P.74)



PS22I48 (P.74)



PS22I49 (P.74)



**PS42F42 (LOCKED)
PS42F43 (NON-LOCKED)
(P.74)**






PS62D01 (P.74)



PS92D01 (P.74)



**TP6041C (NON-LOCK)
(P.75)**



SWITCH INDEX



SWITCH INDEX



LT8-1008I
2P-ON-OFF
(P.79)



LT8-1104
2P-ON-OFF
(P.79)



LT8-1104A
2P-ON-OFF
(P.79)



LT8-1104B
2P-ON-OFF
(P.79)



LT8-1105
2P-ON-OFF
(P.79)



LT8-1105A
2P-ON-OFF
(P.79)



LT8-1105B
2P-ON-OFF
(P.79)



LT8-1107
2P-ON-OFF
(P.79)



LT8-1107A
2P-ON-OFF
(P.79)



LT8-1107M
2P-ON-OFF
(P.79)



LT8-1107N
2P-ON-OFF
(P.79)



LT8-1107O
2P-ON-OFF
(P.79)



LT8-1107L
2P-ON-OFF
(P.80)



LT8-1107P
2P-ON-OFF
(P.80)



LT8-1108
2P-ON-OFF
(P.80)



LT8-1201
2P-ON-OFF
(P.80)



LT8-1202
2P-ON-OFF
(P.80)



LT8-1204
2P-ON-OFF
(P.80)



LT8-1205
2P-ON-OFF
(P.80)



LT8-1208
2P-ON-OFF
(P.80)



LT8-1209
2P-ON-OFF
(P.80)



LT8-1210
2P-ON-OFF
(P.80)



LT8-1212
2P-ON-OFF
(P.80)



LT8-1217
2P-ON-OFF
(P.80)



LT8-1218
2P-ON-OFF
(P.81)



LT8-1219
2P-ON-OFF
(P.81)



LT8-1301B
3P-ON-ON-ON-OFF
(P.81)



LT8-1302
3P-ON-OFF-ON-OFF
LT8-1303A
3P-ON-OFF
(P.81)



LT8-1303
3P-ON-OFF-ON-OFF
LT8-1305A
3P-ON-OFF
(P.81)



LT8-1302B
3P-ON-OFF-ON-OFF
LT8-1303B
3P-ON-ON
(P.81)



LT8-1304A
3P-ON-OFF
(P.81)





LT8-13011
3P-ON-OFF-ON-OFF
LT8-1301A
3P-ON-OFF
(P.81)



LT8-1401
4P-ON-OFF-ON-OFF
LT8-1405A
4P-ON-ON
(P.81)



LT8-1401A
ON
4P-ON-OFF
ON
(P.81)




SWITCH INDEX




BP SERIES
(P.93)



**DIP SWITCH
DAAH SERIES**
(P.101)



**DIP SWITCH
DPAH SERIES**
(P.101)



**DIP SWITCH
DPLAH SERIES**
(P.102)



**DIP SWITCH
DSVH SERIES**
(P.101)



**KEY SWITCH
GT02A1BNN-T**
(P.103)



**KEY SWITCH
GT02A1DNN-T**
(P.103)



**KEY SWITCH
GT02A1ENN-T**
(P.104)



**KEY SWITCH
GT02A2ANN-T**
(P.103)



KS5A
(P.89)



KS5B
(P.89)



KS5C
(P.89)



KS9A
(P.90)



KS9B
(P.90)



KS9C
(P.90)



KT SERIES
(P.94)



**LIGHT TYPE 0
WITHOUT LED**
(P.85)



**LIGHT TYPE E
RING POWER
LOGO**
(P.85)



**LIGHT TYPE E
RING MOVEABLE**
(P.85)



**LIGHT TYPE
POWER LOGO**
(P.82)



**LIGHT TYPE RING
ILLUMNATED
FIXED**
(P.82)



**LIGHT TYPE RING
ILLUMINATED
MOVEABLE**
(P.82)



**LIGHT TYPE
SPOT**
(P.82)



**LIGHT TYPE
WITHOUT LED**
(P.82)



LS600AH SERIES
(P.99)



LS600VH SERIES
(P.99)



LS601VH SERIES
(P.99)



LS701AHP SERIES
(P.100)



MPB22 SERIES
(P.82)



PBL SERIES
(P.91)



PSD SERIES
(P.92)



**ROTARY SWITCH
RSC 1ARM**
(P.105)



**ROTARY SWITCH
RSC 1FRM**
(P.105)



**ROTARY SWITCH
RSC 3ARM**
(P.106)



**ROTARY SWITCH
RSC 3FRM**
(P.107)



**ROTARY SWITCH
RSC 14RM**
(P.105)

SWITCH INDEX



ROTARY SWITCH
RSC 24RM (P.106)



ROTARY SWITCH
RSC 34RM (P.106)



SK SERIES
(P.88)




























SP86N SERIES
(P.96)



SPH SERIES
(P.98)



SPL12 SERIES
(P.87)



SWITCH INDEX



MX-1201-A
(P.113)



TC-0010
(P.108)



TC-12EA
(P.109)



TC-12EB
(P.109)



TC-12ET
(P.109)



TC-024V
(P.108)



TC-0030
(P.113)



TC-0036
(P.113)



TC-0041
(P.113)



TC-0050
(P.113)



TC-0060
(P.113)



TC-0090
(P.113)



TC-0102
(P.108)



TC-0112
(P.108)



TC-0120
(P.108)



TC-0120V
(P.108)



TC-0202
(P.108)



TC-0240
(P.108)



TC-0250
(P.109)



TC-0302
(P.109)



TC-00303A
(P.109)



TC-0402
(P.109)



TC-1193
(P.109)



TC-1194
(P.109)



TC-1195
(P.109)



TC-1197
(P.109)



TC-2401
(P.109)



TC-V033A
(P.113)



TC-V033B
(P.113)



TD-01EA
(P.110)



TD-02XB
(P.110)



TD-03XG
(P.110)



TD-05XB
(P.110)



TD-06XG
(P.110)







TD-07XB
(P.110)



TD-10XA
(P.110)

SWITCH INDEX

TD-11XA
(P.110)TD-12EA
(P.111)TD-12EB
(P.111)TD-12ET
(P.111)TD-13MAA
(P.111)TD-13XA
(P.111)TD-14XA
(P.111)TD-15XA
(P.111)TD-16EA
(P.111)TD-18XA
(P.111)TD-19XA
(P.111)TD-20UA
(P.112)TD-23MU
(P.112)TD-26EA
(P.112)TD-26EU
(P.112)TD-28MU
(P.112)TD-29XU
(P.112)TD-30EA
(P.112)TD-36EA
(P.112)TD-40EA
(P.112)TD-42EA
(P.112)TD-46EU
(P.112)TD-73XA
(P.112)TD-74XA
(P.112)TD-85EU
(P.113)TD-85XU
(P.113)TD-1111G
(P.110)TD-1198
(P.110)TD-1199G
(P.110)TD-1199U
(P.111)TD-1602
(P.111)TS-1147
(P.110)

SWITCH INDEX



MK-12C02
(P.115)



MK-12D10
(P.115)



MK-12D13
(P.115)



MK-12D14
(P.115)



MK-12D70-E
(P.115)



MK-13C01
(P.115)



MK-13D70
(P.115)



MK-14C03
(P.115)



MK-22D10
(P.115)



MK-22D13
(P.115)



MK-22D14
(P.115)



MK-23D38
(P.115)



MS-12C02
(P.114)



MS-12D16
(P.114)



MS-12D17
(P.114)



MS-13D18
(P.114)



MS-13D20
(P.114)



MS-22C01
(P.114)



MS-22D16
(P.114)



MS-22D17
(P.114)



MS-23C01
(P.114)






MS-23D18
(P.114)



MS-23D20
(P.114)



MS-12D16
(P.114)



SWITCH INDEX



SWITCH INDEX



SS24-BBTWQ-R60-R (P.126)



SS31-BBNNQ-RD40-R (P.128)



SS31-BBNNQ-RD60-R (P.128)



SS31-BBNNQ-RS30-R (P.128)



SS31-BBRNQ-LT40-L02-R (P.129)



SS31-RBNNQ-RD40-L02-R (P.128)



SS31-RBNNQ-RT40-L02-R (P.129)



VS12-C11ARC-R (P.144)



VS12-C11BRD-R (P.144)



VS12-M11ARD-R (P.144)



VS12-X11BRC-R (P.144)



RT-L01 SERIES (P.146)



RT-M2 SERIES (P.147)



RT-C01-A SERIES (P.148)



RT-C04 SERIES (P.149)



RT-C08 SERIES (P.150)



RT-C14 SERIES (P.151)



RT-S05 SERIES (P.152)



RT-S06A SERIES (P.156)



RT-P01 SERIES (P.158)











RT-P03 SERIES (P.159)



RT-P04 SERIES (P.159)



RT-S04 SERIES (P.160)




SWITCH INDEX



PJ208A (P.161)



PJ-205D (P.161)



PJ-205A (P.161)



PJ-205C (P.161)



PJ-208 (P.161)



PJ-208D (P.161)



PJ-209 (P.161)




PJ-217 (P.161)



PJ-218 (P.161)



PJ-218C (P.161)



PJ-220 (P.162)



PJ-221 (P.162)



PJ-223 (P.162)



PJ-224 (P.162)



PJ-226 (P.162)



PJ-227 (P.162)



PJ-228 (P.162)



PJ-229 (P.162)



PJ-234 (P.162)



PJ-237 (P.162)



PJ-238 (P.162)



PJ-240 (P.162)



PJ-242C (P.163)



PJ-242C1 (P.163)



PJ-243 (P.163)



PJ-243F (P.163)



PJ-244 (P.163)



PJ-263 (P.163)



PJ-305B (P.163)



PJ-305G (P.163)



PJ-313D (P.163)



PJ-313E (P.163)



PJ-320B (P.163)



PJ-320D
PJ-320DS (P.163)



PJ-320G (P.164)



PJ-321A (P.164)

SWITCH INDEX



PJ-326 (P.164)



PJ-327A (P.164)



PJ-327AN (P.164)



PJ-327C (P.164)



PJ-327E (P.164)



PJ-327F (P.164)



PJ-328 (P.164)



PJ-328B (P.164)



PJ-365 (P.164)




PJ-380
PJ-380B (P.164)



PJ-381
PJ-381B (P.165)



PJ-381C (P.165)



PJ-381C1 (P.165)



PJ-381CN (P.165)




PJ-391 (P.165)



PJ-392 (P.165)



PJ-392B (P.165)



PJ-392D (P.165)




PJ-417 (P.165)



PJ-418 (P.165)



PJ-481 (P.165)



PJ-3160 (P.165)



PJ-3160A (P.166)



PJ-3160C (P.166)



PJ-3160CW (P.166)



PJ-3160D (P.166)



PJ-3160N (P.166)



PJ-3160W (P.166)



PJ-3160X (P.166)



PJ-3161E (P.166)



PJ-3165A (P.166)



PJ-3241 (P.166)



PJ-3246A (P.166)



PJ-3301E (P.166)



PJ-3301F (P.167)



PJ-3301L (P.167)

SWITCH INDEX



PJ-3311E (P.167)



PJ-3311R (P.167)




PJ-3315A (P.167)



PJ-3365R (P.167)
































PJ-3901 (P.167)



PJ-3901A (P.167)



PJ-E66 (P.167)



SWITCH INDEX



PJ-201 (P.168)



PJ-202
PJ-202M (P.168)



PJ-204
PJ-204B (P.168)



PJ-204A (P.168)



PJ-205B (P.168)



PJ-207 (P.168)



PJ-208B (P.168)



PJ-208C (P.168)



PJ-210
PJ-210A (P.168)



PJ-210B
PJ-210C (P.168)



PJ-210D (P.169)



PJ-211 (P.169)



PJ-211A (P.169)



PJ-212 (P.169)



PJ-213 (P.169)



PJ-216 (P.169)



PJ-216A (P.169)



PJ-218A (P.169)



PJ-230 (P.169)



PJ-252 (P.169)



PJ-301
PJ-301M (P.169)



PJ-301C
PJ-301CM (P.169)



PJ-301DM (P.170)



PJ-302 (P.170)



PJ-302M (P.170)



PJ-303
PJ-303M (P.170)



PJ-306 (P.170)



PJ-306B
PJ-306BM (P.170)



PJ-306E (P.170)



PJ-306EM (P.170)



PJ-306F (P.170)



PJ-306G (P.170)



PJ-306M (P.170)



PJ-307 (P.171)



PJ-307A
PJ-307D (P.170)



PJ-307B (P.170)

SWITCH INDEX



PJ-307E (P.170)



PJ-307G (P.171)



PJ-307K (P.171)



PJ-311 (P.171)



PJ-313 (P.171)



PJ-313B (P.171)



PJ-313C (P.171)



PJ-314 (P.171)



PJ-315A (P.171)



PJ-316 (P.171)



PJ-317 (P.171)



PJ-317A (P.171)



PJ-317B (P.172)



PJ-317G (P.172)



PJ-318 (P.172)



PJ-319 (P.172)



PJ-319A (P.172)



PJ-320
PJ-320F (P.172)



PJ-320A
PJ-320AS (P.172)



PJ-320E (P.172)



PJ-321 (P.172)



PJ-322 (P.172)



PJ-323
PJ-323M (P.172)



PJ-324
PJ-324M (P.172)



PJ-325 (P.173)



PJ-325C (P.173)



PJ-325M (P.173)



PJ-327 (P.173)



PJ-328A (P.173)



PJ-328C (P.173)




PJ-333
PJ-333M (P.173)



PJ-334A (P.173)



PJ-335 (P.173)



PJ-340D (P.173)



PJ-340S (P.173)



PJ-341 (P.173)

SWITCH INDEX



PJ-342 (P.173)



PJ-343
PJ-353 (P.174)




PJ-343A
PJ-353A (P.174)




PJ-343B
PJ-353B (P.174)



PJ-352A (P.174)



PJ-355 (P.174)



PJ-358 (P.174)



PJ-359 (P.174)



PJ-362 (P.174)



PJ-362A (P.174)



PJ-366 (P.174)



PJ-372 (P.174)



PJ-375C (P.174)



PJ-378
PJ-378A (P.175)



PJ-378E (P.175)



PJ-381A (P.175)



PJ-384 (P.175)



PJ-392C (P.175)



PJ-395 (P.175)



PJ-601
PJ-601A (P.175)



PJ-602A (P.175)



PJ-603A (P.175)



PJ-605A (P.175)



PJ-609 (P.176)



PJ-609A (P.176)



PJ-609B (P.176)



PJ-609D (P.176)



PJ-610 (P.176)



PJ-611 (P.176)



PJ-612 (P.176)



PJ-625AK (P.176)




PJ-625FK (P.176)



PJ-30120 (P.175)



PJ-30130 (P.175)



SWITCH INDEX



DC-002C (P.177)



DC-011B (P.177)



DC-011C (P.177)



DC-031A (P.177)



DC-033 (P.177)



DC-041 (P.177)



DC-045 (P.177)



DC-045A (P.177)



DC-045B (P.177)



DC-047 (P.177)



DC-049A (P.178)



DC-050 (P.178)



DC-052 (P.178)



DC-055 (P.178)



DC-055A (P.178)



DC-056 (P.178)



DC-056C (P.178)



DC-058 (P.178)



DC-058C (P.178)



DC-085 (P.178)



DC-092 (P.178)



DC-093A (P.178)



DC-094 (P.179)



DC-096 (P.179)



DC-096A (P.179)



DC-096B (P.179)



DC-098 (P.179)









DC-099 (P.179)



DC-135 (P.179)



DC-530 (P.179)



SWITCH INDEX



DC-001 (P.180)



DC-002 (P.180)



DC-002A (P.180)



DC-003 (P.180)



DC-003A (P.180)



DC-004 (P.180)



DC-005 (P.180)



DC-005A (P.180)



DC-005B (P.180)



DC-005C (P.180)



DC-005D (P.181)



DC-006 (P.181)



DC-009 (P.181)



DC-009A (P.181)



DC-009C (P.181)



DC-010 (P.181)



DC-011 (P.181)



DC-011A (P.181)



DC-012 (P.181)



DC-012A (P.181)



DC-012B (P.181)



DC-013 (P.181)




DC-013A (P.182)



DC-013C (P.182)



DC-013G (P.182)



DC-014 (P.182)



DC-015 (P.182)



DC-015C (P.182)



DC-016 (P.182)



DC-016A (P.182)



DC-017 (P.182)



DC-018 (P.182)



DC-019 (P.182)



DC-020 (P.182)



DC-021 (P.183)



DC-022 (P.183)

SWITCH INDEX



DC-022B (P.183)

DC-023
DC-023A (P.183)DC-025
DC-025M (P.183)DC-026
DC-026M (P.183)

DC-027 (P.183)



DC-028 (P.183)



DC-028A (P.183)



DC-029 (P.183)

DC-030
DC-030A (P.183)

DC-030B (P.183)



DC-031 (P.184)

DC-036
DC-036A (P.184)

DC-037 (P.184)



DC-038 (P.184)



DC-044 (P.184)

DC-044A
DC-044B (P.184)

DC-044C (P.184)



DC-044E (P.184)



DC-047A (P.184)



DC-048 (P.184)



DC-051 (P.184)



DC-062 (P.184)



DC-068 (P.185)



DC-081 (P.185)



DC-083 (P.185)



DC-084 (P.185)



DC-091 (P.185)







DC-099A (P.185)



DC-511 (P.185)



DC-531 (P.185)



SWITCH INDEX

USB-A-SL00-D
(P.188)USB-B-RD20
(P.188)USB-B-RD30
(P.188)USB-B-SD20
(P.188)USB-C-PM50
(P.189)USB-C-RD50
(P.188)USB-C-RM50
(P.189)USB-C-RM51
(P.189)USB-C-RM80
(P.189)USB-C-RS80
(P.189)USB-C-SD50
(P.189)USB-H-RA00-S
(P.191)USB-H-RC00-S
(P.191)USB-M-PM10
(P.189)USB-M-PS03
(P.190)USB-M-PS11
(P.190)USB-M-PS20
(P.190)USB-M-RD13
(P.189)USB-M-RM10
(P.189)USB-M-RM11
(P.190)USB-M-RS10
(P.189)USB-M-RS11
(P.189)USB-M-RS12
(P.189)USB-M-SD10
(P.190)