

## FUSE HOLDERS



**FH-1**

Panel mounting (6.3 Amp)  
Fuse link size 5x20 mm  
(Rd/Bk)



**FH-1B**

Panel mounting (6.3 Amp)  
Fuse link size 5x20 mm  
(Rd/Bk) Bakelite material



**FH-1D**

Panel mounting with coin  
slot cap (6.3 Amp)  
fuse link size 5x20 mm



**FH-1S**

Snap mounting, (6.3 Amp)  
fuse link size 5x20 mm  
(Rd/Bk)



**FH-2**

Chassis mounting  
(6.3 Amp) fuse link  
size 5x20 mm



**FH-3**

Chassis mounting  
(10 Amp) fuse link size  
6.3x32 mm (C-DOT)



**FH-5**

Panel mounting  
(10 Amp) fuse link  
size 6.3X32 mm



**FH-52**

Panel mounting  
(30 Amp DC) fuse link  
size 6.3X32 mm



**FH-6**

Panel mounting  
(10 Amp) fuse link  
size 6.3x32 mm



**FH-7**

Panel mounting  
(6.3 Amp) fuse link  
size 5x20 mm (C-DOT)



**HFH-1**

Hanging type  
(4 Amp) fuse link  
size 5x20 mm



**HFH-5**

Hanging type  
(12 Amp) fuse link  
size 6.3x32 mm



**MF-20**

Chassis mounting  
(10 amp) fuse link size  
6.3x32 mm (dual enclosure)



**PBF-1**

PCB mounting  
(6.3 Amp) fuse link size  
5x20 mm (C-DOT)



### **PBF-2**

PCB mounting  
(6.3 Amp) fuse link size  
5x20 mm (C-DOT)



### **PBF-2M**

PCB mounting  
(6.3 Amp) fuse link size  
5x20 mm (C-DOT, CE)



### **PBF-3**

PCB mounting  
(6.3 Amp) fuse link size  
5x20 mm (C-DOT)



### **PBF-4**

PCB mounting  
(6.3 Amp) fuse link size  
5x20 mm (CE)



### **PBF-5**

PCB mounting  
(10 Amp) fuse link  
size 6.3x32 mm



### **PFH-511**

Panel mounting  
(10 Amp) Bayonet cap  
fuse link size 6.3x32 mm



### **PFH-9**

Panel mounting with  
screw in with coin slot  
cap (6.3 Amp) fuse link  
size 5x20 mm